

# Armado Banco con respaldo MB392

Herramienta requerida

⊕ Desarmador de cruz

## Armado

The diagram illustrates the assembly of the MB392 office chair. It shows the seat and backrest components being lowered onto a central vertical post, which is then attached to a four-wheeled base. Three screws, indicated by the ⊕ symbol, are used to secure the backrest to the seat. The seat is shown with a small black tab on its underside. The backrest is shown with a curved support structure. The central post is shown with a small semi-circular cap at its top. The base is shown with four casters. Arrows indicate the downward direction of assembly for the seat, post, and base.